34130584060 Printed in Germany

Repair instructions







Applies to: CG 15-125; CG15-150



Contents

Contents

1		Мос	dels o	described	4
2		Tec	hnica	al data	5
3		Sym	nbols	s used	6
4		Note	es ar	nd requirements	7
5		Safe	ety ir	nstructions	8
6		Тоо	ls, lu	bricants and auxiliary substances required	10
	6.	.1	Star	ndard tools	10
	6.	.2	Spe	cial tools	10
	6.	.3	Lub	ricants and auxiliary substances required	10
7		Tes	t and	diagnostics options	11
8		Disa	assei	mbly	12
	8.	.1	Ren	noving the safety hood and handle	12
	8.	.2	Ren	noving the mains cable	13
		8.2.	1	Removing the CG15-BL mains cable	13
		8.2.	2	Netzkabel entfernen CG15-BLP	14
	8.	.3	Disa	assembling the gearbox	15
		8.3.	1	Removing the lever	15
		8.3.	2	Removing the bearing plate	
		8.3.	3	Disassembling the bearing plate	17
		8.3.	4	Removing the gearbox housing	
		8.3.	5	Disassembling the gearbox housing	
		8.3.	6	Removing the pushbutton	21
	8.	.4	Disa	assembling the housing	22
		8.4.	1	Removing the CG15-BL motor housing	22
		8.4.	2	Removing the CG15-BLP motor housing	24
		8.4.	3	Removing the CG15-BL electronics	25
		8.4.	4	Removing the CG15-BLP electronics	27
	8.	.5	Ren	noving the motor	
		8.5.	1	Removing the motor	
		8.5.	2	Disassembling the rotor	31
9		Ass	emb	ly	
	9.	.1	Ass	embling the motor	32
(ד_ג	9.1. гs	1	Assembling the rotor	





Contents

9.1	.2	Positioning the motor	33
9.2	Ass	embling the housing	36
9.2	.1	Positioning the CG15-BL electronics	36
9.2	.2	Positioning the CG15-BLP electronics	38
9.2	.3	Positioning the CG15-BL motor housing	40
9.2	.4	Positioning the CG15-BLP motor housing	42
9.3	Ass	embling the gearbox	43
9.3	.1	Assembling the gearbox housing	43
9.3	.2	Positioning the gearbox housing	45
9.3	.3	Assembling the bearing plate	46
9.3	.4	Positioning the bearing plate	48
9.3	.5	Positioning the lever	49
9.4	Ass	embling the mains cable	50
9.4	.1	Positioning the BL mains cables	50
9.4	.2	Positioning the BLP mains cables	52
9.5	Pos	itioning the safety hood and handle	54
10 Insp	pectio	on following repairs	55
10.1	Fun	ctionality and safety	55
10.2	Cali	bration	56
11 Lab	elling	g requirement	59





Models described

1 Models described

These repair instructions describe how to repair the following models:

Model	Material number
CG 15-125 BL	7 222 67 7 225 06
CG 15-125 BL Inox	7 222 86 7 225 07
CG 15-125 BLP	7 222 76 7 225 08
CG 15-125 BLP Inox	7 222 85 7 225 09
CG 15-150 BL	7 222 78 7 225 10
CG 15-150 BLP	7 222 77 7 225 11





Technical data

2 Technical data

Technical data

The complete technical data can be found in the operating instructions for the model.

Special tools

The special tools catalogue can be found in the FEIN electronic information system.

Lubricants and auxiliary substances

The lubricants catalogue can be found in the FEIN electronic information system.

Lists of spare parts

Lists of spare parts and exploded views are available online in our spare parts catalogue, which can be accessed via the FEIN website.

Connection diagram

The connection diagram can be found in the FEIN electronic information system.

Documents required for further repair work

- FEIN lubricants catalogue
- FEIN special tools catalogue
- All relevant service communications

Q_TS





Symbols used

3 Symbols used

	Refers to measures for avoiding the risk of injuries.
	Caution: danger of crushing.
	Caution: danger of cutting.
	ESD warning symbol to identify electrically sensitive components and parts.
	Refers to information or instructions that should be followed. Non-observance can result in damage or malfunctions.
	Read the operating instructions.
\odot	This spare part must always be replaced after disassembly.
i	Indicates notes that provide information or instructions that may provide a better understanding and contribute to the more effective use of the product.
	Part of the navigation interface.



yein

Notes and requirements

4 Notes and requirements

Please note

These instructions are only intended for persons with suitable technical training. It is assumed that the reader has mechanical and electrical training.

Only use original FEIN spare parts!

Read the operating instructions for the product before carrying out any repair work.

Provisions

Please note that power tools may only be repaired, maintained and checked by a trained electrician, as improper repair can result in serious risks to the user.

Outside Germany, the regulations applicable in the respective individual country must be observed.

The provisions set out in DIN VDE 0701-0702 should be observed after repairs.

The relevant accident prevention regulations are to be observed during commissioning.

The German Equipment and Product Safety Act [ProdSG] applies for correct use.

Disclaimer

The content of this documentation has been carefully reviewed and produced to the best of our knowledge. C. & E. Fein GmbH assumes no responsibility for the completeness, relevance, quality or correctness of the information provided.

Liability claims against C. & E. Fein GmbH that relate to material or immaterial damage caused by the use or failure to use the information provided or by the use of incorrect or incomplete information are excluded. Claims relating to acts committed intentionally or through gross negligence are categorically excluded.

Version 1.0_Vorlage 2.0

22.04.2024





Safety instructions

5 Safety instructions

5.1 Structure

Signal word for the danger classification.

Type and source of the danger.

Possible consequences.

Measure that must be taken in order to avoid this danger.

5.2 Danger classification

Warning

This warning refers to a dangerous situation. If the situation is not avoided, this may result in severe injuries or death.

A Warning!

Type and source of the danger.

Possible consequences.

Measure that must be taken in order to avoid this danger.

Caution

This warning refers to a potentially dangerous situation. If the situation is not avoided, this may result in slight or minor injuries. This may also be used as a warning against material damage.



Caution!

Type and source of the danger.

Possible consequences.

Measure that must be taken in order to avoid this danger.

Please note





Safety instructions

Indicates a potentially harmful situation. If this situation is not avoided, the product or an object in its environment could be damaged.

Please note:

Type and source of the danger.

Damage to the product or its environment.

Measure that must be taken in order to avoid this danger.

5.3 Information

Indicates notes that provide information or instructions that may provide a better understanding and contribute to the more effective use of the product.



Tip

5.4 ESD protection

Damage from electrostatic charge.

Failure to comply with the safety regulations for ESD protection may cause damage to the electronics.

Only perform assembly/disassembly work on electronics at a workstation with ESD protection.



Avoiding the failure of electronics





Tools, lubricants and auxiliary substances required

6 Tools, lubricants and auxiliary substances required

6.1 Standard tools

Slotted screwdriver	2.5
Plastic hammer	
Torx screwdriver	T15
Torx screwdriver	T20
Punch	6 mm diameter
Arbor press	
Ball bearing support	19 mm; 26 mm
Sleeve	35 mm inner diameter
	19 mm outer diameter 14 mm inner diameter
	42 mm outer diameter 30 mm inner diameter
	20 mm outer diameter 15 mm inner diameter
	27 mm outer diameter 15 mm inner diameter
4x round material	20 mm in diameter Length 60 mm

6.2 Special tools

Drawing-off socket cap	SW0016	
Chuck cone	SW0019, 19 mm diameter	
Chuck cone	SW0019, 26 mm diameter	
Drawing-off plate	SW0011	
Pipe	SW0002	
Assembly aid	SW0069	

6.3 Lubricants and auxiliary substances required

Grease	SM0019	30 / 35 g	Gearbox
Sealant	HS0034	0.2 g	Mains cable, electronics

Version 1.0_Vorlage 2.0	22.04.2024	Page 10 of 59
		- •



yein

Test and diagnostics options

7 Test and diagnostics options

Test data

The permitted parameters for the machine can be found in the FEIN electronic information system.



34130584060 Printed in Germany

Jein

Disassembly

8 Disassembly

8.1 Removing the safety hood and handle

Tools:

- Pin-type face wrench
- Slotted screwdriver




(i) Information



Remove the safety hood as described in the relevant operating instructions.

- 1. Remove the safety hood (1).
- 2. Unscrew the handle (2).



Note!

Missing or damaged O-ring (3).

It cannot be guaranteed that the grinding tools will be installed correctly.

Replace the O-ring.



34130584060 Printed in Germany

yein


Disassembly


8.2 Removing the mains cable


8.2.1 Removing the CG15-BL mains cable

Tools:

- Torx T15
- Slotted screwdriver 2.5 mm







- 1. Unscrew the two screws (1).
- 2. Remove the cover (2).

- 3. Remove the cover (**3**).
- 4. Remove the cable clamp (4).

- 5. Remove the two cables (5).
- 6. Remove the cable grommet (6).



34130584060 Printed in Germany

Disassembly


8.2.2 Removing the mains cable CG15-BLP

Steps that must be completed:


- Removing the leverRemoving the lever -
- Removing the bearing plate -
- Removing the gearbox housing _
- Removing the CG15-BLP motor housing -


Tools:

- Torx T15 -
- Slotted screwdriver 2.5 mm _



- Unscrew the screw (1). 1.
- 2. Remove the cable clamp (2).
- 3. Remove the electronics (3).





Remove the two cables (4).

4.

- Remove the cable grommet (5). 5.
- Remove the eyelet (6). 6.



34130584060 Printed in Germany

yein

Disassembly

8.3 Disassembling the gearbox


8.3.1 Removing the lever

Steps that must be completed:

- Removing the safety hood and handle


Tools:

- Torx T20



- 1. Unscrew the screw (1).
- 2. Remove the lever (2).

- 3. Remove the washer (3).
- 4. Remove the spring (4).



22.04.2024



34130584060 Printed in Germany

Disassembly


8.3.2 Removing the bearing plate


Steps that must be completed:

- Removing the safety hood and handle

Tools:

- Slotted screwdriver 2.0 mm
- Torx T20







1. Remove the sealing ring (1).

- 2. Unscrew the four screws (2).
- 3. Remove the bearing plate (3).

4. Remove the sealing ring (4).

Version 1.0_Vorlage 2.0

22.04.2024

Page 16 of 59



<u>/</u> Jein

8.3.3 Disassembling the bearing plate

Steps that must be completed:


- Removing the lever

Disassembly


- Removing the bearing plate

Tools:

- Arbor press
- Sleeve, 35 mm inner diameter
- Torx T20
- Sleeve, 14 mm inner diameter, 19 mm outer diameter
- Sleeve, 30 mm inner diameter, 42 mm outer diameter



- 1. Press out the shaft (1).
- 2. Remove the gearwheel (2).



- 3. Unscrew the three screws (3).
- 4. Remove the plate (4).

Version 1.0_Vorlage 2.0


22.04.2024



34130584060 Printed in Germany

Fein

Disassembly



5. Press out the grooved ball bearing (1).





Disassembly

8.3.4 Removing the gearbox housing

Steps that must be completed:

- Removing the lever
- Removing the bearing plate

Tools:

- Torx T15
- Cleaning area



1. Unscrew the four screws (1).

- 2. Remove the grease (2).

Q_TS



yeim

Disassembly

8.3.5 Disassembling the gearbox housing

Steps that must be completed:

- Removing the lever
- Removing the bearing plate
- Removing the gearbox housing
- Removing the CG15-BL/CG15-BLP motor housing
- Removing the motor

Tools:

- Circlip pliers
- Internal puller




2. Remove the circlip (**2**).

1.

3. Remove the bearing (3).

Remove the air guide ring (1).



Q_TS



yeim

8.3.6 Removing the pushbutton.

Steps that must be completed:

- Removing the lever

Disassembly

- Removing the bearing plate

Tools:

- Slotted screwdriver
- Punch, 3 mm



1. Remove the pushbutton (1).

- 2. Remove the spring (2).
- 3. Remove the bolt with sealing ring (3).







Disassembly

8.4 Disassembling the housing

8.4.1 Removing the CG15-BL motor housing

Steps that must be completed:

- Removing the lever
- Removing the bearing plate
- Removing the gearbox housing

Tools:

- Blade
- Slotted screwdriver



1. Cut through the label (1).




2. Cut through the label (2).



34130584060 Printed in Germany

Disassembly











3. Remove the slide switch (1).

- 4. Remove the six screws (2).
- 5. Remove the cover (3).

- 6. Pull out the gearbox housing (4) by approx. 5 mm.
- 7. Remove the housing shell (5).

8. Remove the control rod (6).

9. Remove the spring (7).

All rights reserved by FEIN, especially in case of property rights applications. FEIN retains all rights of disposal, such as copying and circulation.



34130584060 Printed in Germany

Fein

Disassembly


8.4.2 Removing the CG15-BLP motor housing


Steps that must be completed:


- Removing the lever
- Removing the bearing plate
- Removing the gearbox housing

Tools:

- Torx T15







1. Unscrew the four screws (1).

- 2. Pull out the gearbox housing (2) by approx. 5 mm.
- 3. Remove the housing shell (3).

- 4. Remove the switch rail (4).
- 5. Remove the spring (5).

- 6. Remove the seal (6).
- 7. Remove the pin (7).
- 8. Remove the inhibitor (8).
- 9. Remove the spring (9).

Version 1.0_Vorlage 2.0

22.04.2024

Page 24 of 59

All rights reserved by FEIN, especially in case of property rights applications. FEIN retains all rights of disposal, such as copying and circulation.



Disassembly


8.4.3 Removing the CG15-BL electronics

Steps that must be completed:

- Removing the CG15-BL mains cable -
- Removing the lever -
- Removing the bearing plate _
- Removing the gearbox housing -
- Removing the CG15-BL motor housing


Tools:

-Slotted screwdriver - 2.5 mm



1. Remove the optical cable (1).

- 2. Remove the switch (2).
- 3. Remove the motor (3) together with the electronics (4).



2

Δ

3

- 4. Remove the plug (5).
- 5. Remove the plug (6).






34130584060 Printed in Germany

Jein

Disassembly



6. Remove the three plugs (1).



34130584060 Printed in Germany

Fein

Disassembly


8.4.4 Removing the CG15-BLP electronics

Steps that must be completed:

- Removing the CG15-BLP mains cable


Tools:

- Slotted screwdriver - 2.5 mm



- 1. Remove the optical cable (1).
- 2. Remove the switch (2).
- 3. Remove the motor (3) with the electronics (4).

- 4. Remove the plug (5).
- 5. Remove the plug (6).



6. Remove the three plugs (7).





Disassembly

8.5 Removing the motor


8.5.1 Removing the motor

Steps that must be completed:


- Removing the lever
- Removing the bearing plate
- Removing the gearbox housing
- Removing the CG15-BL/CG15-BLP electronics

Tools:

- Open-ended spanner, WAF 10
- Open-ended spanner, WAF 6
- SW0069



1. Place the tool (1) on the magnetic holder.



2. Remove the stator housing (2).

(i) Information

Secure the stator housing (2).

Slide the rotor (3) out of the stator housing (2) using the tool (1).


3. Remove the rubber socket (4).







Disassembly





4.

5.

Magnet incorrectly positioned (1) in relation to the rotor. The motor will not work correctly.

Note the position of the magnetic holder (1).

The rotor and magnet must be exactly aligned with one another.




i) Information

Pull off the magnetic holder (2).

Carefully loosen the magnetic holder (2) using the screwdriver.

Then pull it off manually.





6.

Note!

Do not clamp the rotor (5) in a vice.

This will make the rotor unusable.

Unscrew the nut (3).

Use the spanner flats (4) of the rotor shaft to hold the nut when loosening it.

7. Remove the rotor (5).



The electronics are not calibrated after the rotor (5) has been replaced.

The motor will not work correctly.

Follow the calibration process described in <u>Section 10.2</u> after installation.

8. Remove the pinion (6).




yein

Disassembly



- 9. Press out the pinion (6).
- 10. Unscrew the three screws (1).
- 11. Remove the intermediate gear box (2).



Version 1.0_Vorlage 2.0

22.04.2024



34130584060 Printed in Germany



Disassembly

8.5.2 Disassembling the rotor

Steps that must be completed:

- Removing the motor


Tools:

- SW0016
- SW0019, 19 mm diameter



Pull off the grooved ball bearing (1). Note!

The bearing and rubber socket (2) are not interchangeable. The fan wheel (3) cannot be assembled safely. Replace the assembly if necessary.





Assembly

9 Assembly

9.1 Assembling the motor

9.1.1 Assembling the rotor

Tools:

- Arbor press
- Sleeve, 7 mm inner diameter



1. Press on the deep groove ball bearing (1).

- 2
- 2. Position the magnet (2).



Magnet incorrectly positioned (2) in relation to the rotor.

The motor will not work correctly.

The rotor and magnet are exactly aligned with one another and can only be repaired together.



The rotor is not calibrated with the electronics.

The motor will not work correctly.

Follow the calibration process after replacement. See <u>Section</u> 10.2





34130584060 Printed in Germany



Assembly

9.1.2 Positioning the motor

Steps that must be completed:

- Fitting the rotor
- Assembling the gearbox housing

Tools:

- Arbor press
- Sleeve, 13 mm diameter
- Open-ended torque spanner, WAF 10 mm
- Open-ended spanner, WAF 6 mm



Press on the washer (1).





Ensure that the washer (1) is in the correct position.



1.

2. Position the rotor (2).





- 3. Position the pinion (3).
- 4. Screw in the nut (4) [7 Nm].



Do not clamp the rotor (5) in a vice.

This will make the rotor unusable.

Use the spanner flats (6) of the rotor shaft to hold the nut when tightening it.

Page 33 of 59


All rights reserved by FEIN, especially in case of property rights applications. FEIN retains all rights of disposal, such as copying and circulation.



34130584060 Printed in Germany



Assembly






- 5. Position the intermediate gear box (1).
- 6. Screw in the three screws (2) [1.2 Nm].

7. Position the rubber socket (3).





- 8. Position the tool (4) on the magnet.
- 9. Position the stator housing (5).

(i) Information

Secure the stator housing (5).


Push the rotor (6) together into the stator housing (5) using the tool (7) as a guide.


Ensure that the stator housing is in the correct position in relation to the gearbox.

Page 34 of 59



Assembly





10. Remove the tool (8).


11. Check the positioning.



Magnet incorrectly positioned (2).

This will damage the rotor and make it unusable.

If the magnet is incorrectly positioned (2), ensure that the rubber socket is seated and repeat steps '7' to '10' until the magnet is positioned centrally (1).







34130584060 Printed in Germany



Assembly


9.2 Assembling the housing

9.2.1 Positioning the CG15-BL electronics

Steps that must be completed: Positioning the motor Position the three plugs (1). 1. Note! Do not swap the connections. The motor will not work correctly. Follow the applicable connection diagram. 2. Position the plug (2). Position the plug (3). 3. Position the electronics (4). 4. Note! Do not position the electronics (4) outside the guide. The motor will not work correctly. Follow the housing guides and avoid cables being crushed. 5 5. Position the optical cable (5).

Assembly





- 6. Position the switch (1).
- 7. Position the cables (2).
- 8. Position the motor (3).

Q_TS



34130584060 Printed in Germany





Assembly

9.2.2 Positioning the CG15-BLP electronics

Steps that must be completed:

- Positioning the motor






1. Position the three plugs (1).



Note!

Do not swap the connections. The motor will not work correctly. Follow the applicable connection diagram.

- 2. Position the plug (2).
- 3. Position the plug (3).



4. Position the electronics (4).




Do not position the electronics (4) outside the guide. The motor will not work correctly.

Follow the housing guides and avoid cables being crushed.





Assembly



- 5. Position the optical cable (1).
- 6. Position the cables (2).
- 7. Position the switch (3).
- 8. Position the motor (4).



34130584060 Printed in Germany

Assembly


9.2.3 Positioning the CG15-BL motor housing


Steps that must be completed:

- Positioning the CG15-BL electronics


Tools:

- Torx T15









- 1. Position the spring (1).
- 2. Position the control rod (2).

- 3. Position the housing half (3).
- 4. Position the gearbox housing (4).

- 5. Screw in the four screws (5) [1.5 Nm].
- 6. Position the cover (6).
- 7. Screw in the two screws (7) [1.5 Nm].



34130584060 Printed in Germany

Assembly



8. Press on the slide switch (1).



Page 41 of 59



34130584060 Printed in Germany

Vein

Assembly


9.2.4 Positioning the CG15-BLP motor housing


Steps that must be completed:

- Positioning the CG15-BLP electronics

Tools:

- Torx T15





- 2. Position the inhibitor (2).
- 3. Position the pin (3).
- 4. Position the seal (4).

5.


6.




- Position the housing half (7).
 Position the gearbox housing (8).

Position the switch rail (5).

Position the spring (6).





9. Screw in the four screws (9) [1.5 Nm].

All rights reserved by FEIN, especially in case of property rights applications. FEIN retains all rights of disposal, such as copying and circulation.



34130584060 Printed in Germany

Yein

Assembly

9.3 Assembling the gearbox

9.3.1 Assembling the gearbox housing

Tools:

- Arbor press
- Sleeve, 25 mm diameter
- Circlip pliers



- 1. Position the bolt with sealing ring (1).
- 2. Position the spring (2).

3. Press on the pushbutton (3).






Assembly

34130584060 Printed in Germany

Fein





- 4. Press in the bearing (1).
- 5. Position the circlip (2).

6. Position the air guide ring (**3**).



34130584060 Printed in Germany



Assembly

9.3.2 Positioning the gearbox housing

Steps that must be completed:

- Positioning the CG15-BL/CG15-BLP motor housing


Tools:

- Torx T15
- SM0019



1. Screw in the four screws (1) [2.7 Nm].

2. Fill the gearbox housing (2) with SM0019 (3).



(i) Information

CG15-125 BL / BLP **30 g** CG15-125 BL / BLP Inox; CG15-150 BL / BLP **35 g**



Assembly

34130584060 Printed in Germany

yeim

9.3.3 Assembling the bearing plate

Tools:

- Arbor press
- Sleeve, 19 mm inner diameter, 27 mm outer diameter
- Sleeve, 12 mm inner diameter, 20 mm outer diameter
- Torx T20



 1. Press in the grooved ball bearing (1).

- 2. Position the plate (2).
- 3. Screw in the three screws (3) [2.4 Nm].


Version 1.0_Vorlage 2.0




Assembly

34130584060 Printed in Germany

Yeim





4. Press in the shaft (1).


- 5. Press the gear wheel (2) onto the shaft.
- 6. Position the washer(s) (3).



Non-compliance with gear backlash.

The gearbox will be subject to increased wear.

The number of shims (3) required depends on the parameter determined after using the special tool SW0066.





Assembly

34130584060 Printed in Germany



9.3.4 Positioning the bearing plate


Steps that must be completed:

- Assembling the bearing plate
- Positioning the stator

Tools:

- Torx T20







1.

Ensure that the position of the hole (3) is correct.

3. Screw in the four screws (4) [3.8 Nm].

Position the sealing ring (1).

4. Position the sealing ring (5).



Version 1.0_Vorlage 2.0

22.04.2024

Page 48 of 59

All rights reserved by FEIN, especially in case of property rights applications. FEIN retains all rights of disposal, such as copying and circulation.




Assembly

Steps that must be completed:

- Positioning the bearing plate

Tools:

- Torx T20





- 5. Position the spring (1).
- 6. Position the screw (2).
- 7. Position the washer (3).

- 8. Position the lever (4).
- 9. Screw in the screw (5) [2.2 Nm].

Version 1.0_Vorlage 2.0



yeim

Assembly


9.4 Assembling the mains cable

9.4.1 Positioning the BL mains cables

Tools:

- Slotted screwdriver 2.5 mm
- Torx T15







1. Position the cable grommet (1).

2. Position the two cables (2).



The cable labelling may differ.

Follow the applicable connection diagram.


- 3. Seal the inner connection terminal (3) all round with 2 g of HS0034.
- 4. Position the cover (4).



34130584060 Printed in Germany



Assembly



- 5. Position the cable clamp (1).
- 6. Screw in the screw (2) [1.5 Nm].

4

- 7. Position the cover (**3**).
- 8. Screw in the two screws (4) [1.5 Nm].




Assembly




9.4.2 Positioning the BLP mains cables

Tools:

- Slotted screwdriver 2.5 mm
- Torx T15



- 1. Position the eyelet (1).
- 2. Position the cable grommet (2).





3. Position the two cables (3).



The cable labelling may differ. Follow the applicable connection diagram.

4. Seal the inner connection terminal (4) all round with 2 g of HS0034.






5. Position the cover (5).





Assembly





6. Position the electronics (1).



Follow steps '4' to '8' in Section 9.2.2.

- 7. Position the cable clamp (2).
- 8. Screw in the screw (3) [1.5 Nm].
- 9. Position the motor housing (4).



Follow steps '5' to '9' in Section 9.2.4.



Assembly



9.5 Positioning the safety hood and handle




) Information

i

Position the safety hood as described in the relevant operating instructions.

- 1. Position the safety hood (1).
- 2. Screw in the handle (2).



Note!

Missing or damaged O-ring (3).

It cannot be guaranteed that the grinding tools will be installed correctly.

Replace the O-ring.





10 Inspection following repairs

10.1 Functionality and safety

A visual and functional check as well as a professional electrical safety test must always be performed after carrying out repair and maintenance work. The regulations and legal requirements applicable in the respective country apply.

Minimum tests recommended for this type of machine:

Always:	Visual inspection
	Speed check
	Insert tool
	Test on metal with a grinding or polishing disc
Mains-operated machines:	Electrical safety test
If restart lock present:	Check restart lock
If brake present:	Check brake functionality after switching off
	[maximum 2 s to standstill]
If soft start present:	Check slow increase to operating speed

Q_TS





10.2 Calibration

The electronics must be calibrated after motor components and/or electronics have been replaced. Calibration requires either an automatic or manual calibration request in the electronics software depending on the type of repair:

Repair:	Motor remains	O Motor components
Electronics remain	Not applicable	Manual
Electronics (brand new)	Automatic	Automatic

Special case: The calibration request must also be set up manually if functioning used electronics are installed.

An NFC-capable programming device and NFC software are required to start the calibration manually. Follow these steps:

- Start the software
- Connect the programming device
- Scan NFC chip <Scan once> [Scan position on speed dial]
- Click on UID number
- Enter 'AB CD EF AF' in block 09

Block 9 - Data: before calibration:

File Reader Tags Demos H	eip					
ype UID	User Memory ×					
E002586118954B94	Select a tag: E002586118954B94 (M24LR04E)	Sector	Block	Data	ASCII	
	Tag size: 128 blocks	00	00	00 00 00 01		
	5	00	01	00 00 00 00		
	Addressing mode Blocks Bytes	00	02	00 00 00 00		
		00	03	01 D5 8B 9B	.ÕDD	
	Unit selection 🔵 Hexadecimal 💿 Decimal	00	04	56 30 36 31	V 0 6 1	
		00	05	00 00 00 00		
	From block: 0d 0	00	06	00 00 00 00		
	Size (in blocks): 0d 128	00	07	00 00 00 00		
		00	08	00 00 00 EE	î	
	Sector Security Status	00	09	AB CD EF AF	«Íï	
	Read memory	00	10	01 A0 01 A0	a " a "	
		00	11	00 00 01 90		
	At block: 0d 0	00	12	00 1E 00 37	7	
		00	13	00 00 01 1A		
lect Inventory Protocols:	Write File to memory	00	14	00 00 00 05		
ISO15693/NFC Type5		00	15	00 00 00 9E		
ISO14443-A/NFC Type2 & Type4A	Pattern 0x 00 Overwrite CCFile	00	16	00 00 00 00		
ISO14443-B/NFC Type4B	Pattern ox oo	00	17	00 00 00 15		
ISO14443-B/SRi/ST25TB	Write pattern to memory	00	18	00 00 00 00		
TYPE1/TOPAZ		00	19	00 00 00 00		
ISO18092/TYPE3		00	20	00 00 00 00		
PICOPASS	Dump Data Table to File	00	21	00 00 00 00		
	Compare Data Table with File	00	22	00 00 00 00		
Scan Once	- compare bata table martine	00	23	00 00 00 00		
Constitution Const	Command Status:	00	24	00 00 00 00		
Continuous Scan		00	25	00 00 00 00		

Q_	TS
----	----

Version 1.0_Vorlage 2.0

22.04.2024

Page 56 of 59

All rights reserved by FEIN, especially in case of property rights applications. FEIN retains all rights of disposal, such as copying and circulation.






Start calibration after the next switch-on



CG15 BL:



CG15 BLP:







- 1. Connect the mains cable (1) to the power supply.
- 2. Set the speed selection (2) to maximum.
- 3. Power up the machine [approx. 3 seconds].



Information

The LED display (3) is flashing.

The speed of the machine is reduced, regardless of the set speed level.

The brake function is not active.

Up to eight switch-on processes may be necessary.

- Switch off the machine. 4.
- Wait for the machine to come to a standstill. 5.



If the machine has already switched itself off, repeat step '2'.

- 6. Switch the machine on again to check that the calibration was successful.
- 7. Check the speed.
- Switch off the machine and check the brake function. 8.



The LED display (3) is lit up continuously.

The maximum speed of the machine is now available.

The brake function is active.






Calibration check with NFC software

- Start the software
- Connect the programming device
- Scan NFC chip <Scan once> [Scan position on speed dial]
- Click on UID number
- Mew entry in block 09:

Status	Minimum value	Entry	Maximum value	Measure
\checkmark	00 00 00 AF ≤	[Value]	≤ 00 00 00 BD	Save and close
0	00 00 00 AF >	[Value]	> 00 00 00 BD	Repeat calibration request

Block 9 - Data after successful calibration:



22.04.2024

Version 1.0_Vorlage 2.0



Page 58 of 59



Labelling requirement

11 Labelling requirement



CG15-BL

CG15-125BL 2009 80 Htt 1000 15 2023-010000 CC00 80 Htt 1000 15 2023-01000 15 2023-010000 15 2023-00000 15 2023-00000 15 2023-00000 15 2023-00000 15 2023-00000 15 2023-00000 15 2000000 15 20000 15 200000 15 200000 15



3

CG15-BLP

CG15-125BLP Type plate (2)

CG15-BL USA/Canada

WARNING-To motuce the fact of they, use only accessed is raided at hest equal to the only accessed is raided at hest equal to WARNING-To notice to shot of they, hence use proof guards when guards. AVERTISSEMENT-Pour redute to freque do ideaure, utiliser und at a deman montrole motigate sur frequencies at a montrole observer, utiliser topication to freque do bibleour. They are redute a determined at a state of the montrole observer, utiliser topication to refreque do bibleour.

Safety notice (3)

Type plate (1)



CG15-BLP USA/Canada

WARNING-To index the first style on only consistent statistic of beneficiaria in the mechanica guided in the ball. WARNING-To make the first statistic horizon ab ball. AVERTISSEMENT-pure reducts account of the statistic of the statistic account of the statistic of the statistic of the statistic account of the statistic of the statistic of the statistic account of the statistic of the statistic of the statistic account of the statistic of the statistic of the statistic account of the stat	Safety notice (4)
prozenie de l'herner en l'herner	

Version 1.0_Vorlage 2.0

