34130533060 Printed in Germany

Repair instructions





Applies to: KFH17-15R; KFH17-15RT



Contents

Contents

1	Models described				4
2	2 Technical data				5
3	Symbols used				6
4	Notes and requirements				7
5	Safety instructions				8
6	Тос	ols, lu	bricants and auxiliary substances required		10
	6.1	Star	ndard tools		10
	6.2	Spe	cial tools		12
	6.3	Lub	ricants and auxiliary substances required		13
7	Tes	t and	diagnostics options		14
8	Disa	asser	nbly		15
	8.1	Ren	noving the milling head		15
	8.1.	.1	Removing the guide plate unit		15
	8.1.	.2	Removing the guide plate unit		16
	8.1.	.3	Removing the handle (milling head)		17
	8.1.	.4	Removing the gearbox unit		18
	8.2	Ren	noving the gearbox unit		19
	8.2.	.1	Remove flywheel		19
	8.2.	.2	Removing the crown wheel		21
	8.2.	.3	Removing the drive shaft (with needle bearing)		22
	8.2.	.4	Removing the grooved ball bearing		24
	8.2.	.5	Removing the drive shaft		25
	8.2.	.6	Removing the grooved ball bearing		27
	8.3	Ren	noving the handle		28
	8.4	Ren	noving the housing		30
	8.4.	.1	Removing the electronics		30
	8.4.	.2	Removing the carbon brushes		31
	8.4.	.3	Removing the gearbox housing		32
	8.5	Ren	noving the motor		35
	8.5.	.1	Removing the stator		35
	8.5.	.2	Removing the armature		37
	8.5.	.3	Disassembling the armature		38
С	8.5. -sc_cs		Removing the gearbox housing Version 1.0	16.04.2020	40 Page 2 of 75





Contents

9	А	ssemb	ly	42
	9.1	Ass	embling the motor	42
	9	0.1.1	Assembling the armature	42
	9).1.2	Positioning the armature	43
	9	0.1.3	Fitting the stator	44
	9.2	Fitti	ng the housing	47
	9	.2.1	Assembling the gearbox housing	47
	9	.2.2	Positioning the gearbox housing	48
	9	.2.3	Positioning the carbon brushes	49
	9	.2.4	Fitting the switch	52
	9	.2.5	Positioning the electronics	53
	9.3	Ass	embling the handle	55
	9	.3.1	Assembling the handle (applies to KFH17-15R)	55
	9	.3.2	Assembling the handle (applies to KFH17-15RT 120V)	
	9.4	Ass	embling the milling head	60
	9	.4.1	Assembling the grooved ball bearing	60
	9	.4.2	Assembling the drive shaft	61
	9	.4.3	Assembling the flywheel	63
	9	.4.4	Assembling the grooved ball bearing	65
	9	.4.5	Assembling the drive shaft (with needle bearing)	
	9	.4.6	Assembling the crown wheel	68
	9	.4.7	Assembling the gearbox unit	
	9	.4.8	Assembling the handle (milling head)	72
		.4.9	Assembling the guide plate unit	
1() Ir	nspectio	on following repairs	75



Models described

1 Models described

These repair instructions describe how to repair the following models:

Model	Material number
KFH17-15R	7 238 18
KFH17-15RT	7 238 19





2 Technical data

Technical data

The complete technical data can be found in the operating instructions for the model.

Special tools

The special tools catalogue can be found in the FEIN electronic information system.

Lubricants and auxiliary substances

The lubricants catalogue can be found in the FEIN electronic information system.

Lists of spare parts

Lists of spare parts and exploded views are available online in our spare parts catalogue, which can be accessed via the FEIN website.

Connection diagram

The connection diagram can be found in the FEIN electronic information system.

Documents required for further repair work

- FEIN lubricants catalogue
- FEIN special tools catalogue
- All relevant service communications





Symbols used

3 Symbols used

Z	<u>^</u>

Refers to measures for avoiding the risk of injuries.

Refers to information or instructions that should be followed. Non-observance can result in damage or malfunctions.



Read the operating instructions.



Indicates notes that provide information or instructions that may provide a better understanding and contribute to the more effective use of the product.

Part of the navigation interface.



Fein

Notes and requirements

4 Notes and requirements

Please note

These instructions are only intended for persons with suitable technical training. It is assumed that the reader has mechanical and electrical training.

Only use original FEIN spare parts!

> INFORMATION

Read the operating instructions for the product before carrying out any repair work.

Provisions

Please note that power tools may only be repaired, maintained and checked by a trained electrician, as improper repair can result in serious risks to the user.

Outside Germany, the regulations applicable in the relevant country must be observed.

The provisions set out in **DIN VDE 0701-0702** should be observed after repairs.

The relevant accident prevention regulations are to be observed during commissioning.

The German Equipment and Product Safety Act [ProdSG] applies for correct use.

Disclaimer

The content of this documentation has been carefully reviewed and produced to the best of our knowledge. C. & E. Fein GmbH assumes no responsibility for the completeness, relevance, quality or correctness of the information provided.

Liability claims against C. & E. Fein GmbH that relate to material or immaterial damage caused by the use or failure to use the information provided or by the use of incorrect or incomplete information are excluded. Claims relating to acts committed intentionally or through gross negligence are categorically excluded.





Safety instructions

5 Safety instructions

5.1 Structure

SIGNAL WORD FOR THE DANGER CLASSIFICATION.


Possible consequences.

Measure that must be taken in order to avoid this danger.

5.2 Danger classification

Warning

This warning refers to a dangerous situation. If the situation is not avoided, this may result in severe injuries or death.



Caution

This warning refers to a potentially dangerous situation. If the situation is not avoided, this may result in slight or minor injuries. This may also be used as a warning against material damage.

CAUTION!


Type and source of the danger.

Possible consequences.

Measure that must be taken in order to avoid this danger.

Please note

Indicates a potentially harmful situation. If this situation is not avoided, the product or an object in its environment could be damaged.





Fein

Safety instructions

5.3 Information

Indicates notes that provide information or instructions that may provide a better understanding and contribute to the more effective use of the product.

í	INFORMATION	
Тір		



Jein

Tools, lubricants and auxiliary substances required

6 Tools, lubricants and auxiliary substances required

6.1 Standard tools

Dial gauge				
Arbor press				
Plastic hammer				
Cross-head screwdriver	PH2			
Socket head wrench	3 mm			
Socket head wrench	4 mm			
Socket head wrench	5 mm			
Circlip pliers	inside; outside			
Hook and pin wrench	95/100			
Open-end wrench	Size 15			
Open-end wrench Slotted screwdriver	Size 15 small			
	0.20 10			
Slotted screwdriver	small			
Slotted screwdriver	small T15			
Slotted screwdriver	small T15 T20			
Slotted screwdriver Torx	small T15 T20 T25			
Slotted screwdriver Torx Punch	small T15 T20 T25 3 mm diameter			



Fein

Tools, lubricants and auxiliary substances required

6.1 Standard tools

Sleave	10 mm inner diemeter
Sleeve	13 mm inner diameter
	20 mm inner diameter
	30 mm outer diameter
	37 mm outer diameter
	41 mm outer diameter
	47 mm outer diameter
	17 mm outer diameter 11 mm inner diameter
	40 mm outer diameter 26 mm inner diameter
	36 mm outer diameter 23 mm inner diameter
	30 mm outer diameter 18.5 mm inner diameter
	40 mm outer diameter 30 mm inner diameter
	55 mm outer diameter 40 mm inner diameter
	65 mm outer diameter 55 mm inner diameter
	89 mm outer diameter 79 mm inner diameter
Pipe	75 mm outer diameter 72 mm inner diameter L=80 mm



Fein

Tools, lubricants and auxiliary substances required

6.2 Special tools

Drawing-off socket cap		64104150008
Chuck cone	19 mm diameter	64107019007
	26 mm diameter	64107026000
Drawing-off plate		64102069007
Pipe		64101002004
Assembly aid		64122121010
Pressure piece		64122003000
Extractor tool		64104101002
Mounting device		64122134000



yein

Tools, lubricants and auxiliary substances required

6.3 Lubricants and auxiliary substances required

The manufacturer's specifications for the lubricants used can be found in the FEIN lubricants catalogue.

Grease	SM 0021
Grease	SM 0024
Grease	SM 0022
Thread locking compound	Loctite 242

	5
20 g	Gearbox
n/a	Mounting springs
n/a	Mounting of indexable inserts
n/a	Screws



Jein

Test and diagnostics options

7 Test and diagnostics options

Test data

The permitted parameters for the machine can be found in the FEIN electronic information system.



Milling

Fein

Disassembly

8 Disassembly

8.1 Removing the milling head

8.1.1 Removing the guide plate unit

Tools:

- Socket head wrench, 5 mm



(i) INFORMATION

Warm up the screws using a hot air gun because they have been glued in with a thread locking compound.

- 1. Unscrew the three screws (1).
- 2. Remove the guide plate unit (2).









8.1.2 Removing the guide plate unit

Tools:

- Torx T20
- Torx T25
- Open-end wrench size 15







Warm up the screws using a hot air gun because they have been glued in with a thread locking compound.

- 1. Unscrew the four screws (1).
- 2. Remove the guide plate (2).
- 3. Unscrew the four screws (3).
- 4. Unscrew the holder (4).

- 5. Unscrew the screw (5).
- 6. Unscrew the locking knob (6).
- 7. Remove the sleeve (7).







8.1.3 Removing the handle (milling head)

Steps that must be completed:

- Removing the guide plate unit


Tools:

- Socket head wrench, 3 mm
- Socket head wrench, 5 mm



- 1. Unscrew the four screws (1).
- 2. Remove the holder (2).

- 1. Unscrew the two screws (3).
- 2. Remove the handle (4).







8.1.4 Removing the gearbox unit

Steps that must be completed:

- Removing the guide plate unit
- Removing the handle

Tools:


- Torx T25
- Socket head wrench, 4 mm
- Plastic hammer



(i) INFORMATION

Warm up the screws using a hot air gun because they have been glued in with a thread locking compound.

1. Unscrew the four screws (1).



2. Remove the bearing housing (2).

- 3. Unscrew the four screws (3).
- 4. Remove the housing (4).

C-SC_CSSM

Version 1.0

16.04.2020

Page 18 of 75

All rights reserved by FEIN, especially in case of property rights applications. FEIN retains all rights of disposal, such as copying and circulation.



Jein

Disassembly

8.2 Removing the gearbox unit


8.2.1 Remove flywheel

Steps that must be completed:

- Removing the guide plate unit
- Removing the handle
- Removing the gearbox unit

Tools:

- Socket head wrench, 3 mm
- Hook and pin wrench 95/100
- Mounting device 64122134000



(i) INFORMATION

Remove the spring magazine (1) using screws (M5x20). Watch out for the springs, they can fall out.

- 1. Fix the bearing housing with the mounting device.
- 2. Remove the spring magazine (1).





Jein

Disassembly

8.2.1 Remove flywheel



- 3. Fix the bearing housing with the mounting device.
- 4. Remove the flywheel (1).






8.2.2 Removing the crown wheel

Steps that must be completed:

- Removing the guide plate unit
- Removing the handle
- Removing the gearbox unit

Tools:

- Torx T15
- Extractor tool 64104101002
- Circlip pliers



(i) INFORMATION

Use a new circlip for assembly each time.

- 1. Remove the circlip (1).
- 2. Remove the washer (2).
- 3. Remove the crown wheel (3).





(i) INFORMATION

The sealing ring (4) is destroyed during removal and must be replaced.

- 4. Remove the sealing ring (4).
- 5. Remove the shims (5).

16.04.2020

Page 21 of 75

All rights reserved by FEIN, especially in case of property rights applications. FEIN retains all rights of disposal, such as copying and circulation.





8.2.3 Removing the drive shaft (with needle bearing)

Steps that must be completed:

- Removing the guide plate unit
- Removing the handle
- Removing the gearbox unit
- Removing the housing

Tools:

- Arbor press
- Sleeve, 65 mm outer diameter, 55 mm inner diameter
- Sleeve, 20 mm inner diameter
- Punch, 3 mm diameter
- Circlip pliers



(i) INFORMATION

Use a new circlip for assembly each time.

- 1. Remove the circlip (1).
- 2. Remove the washer (2).



3. Press out the drive shaft (3).



Milling

Disassembly



8.2.3 Removing the drive shaft (with needle bearing)



i Information

Press out the need bearing carefully. Remove the needle bearing only if necessary.

The needle bearing is destroyed during removal and must be replaced.

- 4. Press out the needle bearing (1).
- 5. Remove the washer (2).







8.2.4 Removing the grooved ball bearing

Steps that must be completed:

- Removing the guide plate unit
- Removing the handle
- Removing the gearbox unit
- Removing the drive shaft
- Removing the crown wheel

Tools:

- Arbor press
- Sleeve, 37 mm outer diameter



(i) INFORMATION

The grooved ball bearing (1) is destroyed during removal and must be replaced.

1. Press out the grooved ball bearing (1).





34130533060 Printed in Germany



8.2.5 Removing the drive shaft

Steps that must be completed:

- Removing the guide plate unit
- Removing the handle
- Removing the gearbox unit
- Removing the drive shaft
- Removing the crown wheel

Tools:


- Arbor press
- Sleeve, 89 mm outer diameter, 79 mm inner diameter
- Slotted screwdriver



(i) Information

The sealing ring (1) is destroyed during removal and must be replaced.

1. Remove the sealing ring (1).



2. Press out the drive shaft (2).





8.2.5 Removing the drive shaft



i INFORMATION

The sealing ring (1) is destroyed during removal and must be replaced.

3. Remove the sealing ring (1).



i Information

The sealing ring $(\mathbf{2})$ is destroyed during removal and must be replaced.

4. Remove the sealing ring (2).






8.2.6 Removing the grooved ball bearing

Steps that must be completed:

- Removing the guide plate unit
- Removing the handle
- Removing the gearbox unit
- Removing the drive shaft
- Removing the crown wheel

Tools:

- Arbor press
- Sleeve, 89 mm outer diameter, 79 mm inner diameter
- Sleeve, 47 mm outer diameter
- Slotted screwdriver



(i) INFORMATION

Note the recess when removing the retaining ring.

1. Remove the circlip (1).



i) INFORMATION

The grooved ball bearing (2) is destroyed during removal and must be replaced.

2. Press out the grooved ball bearing.






8.3 Removing the handle


Tools:

- Torx T15
- PH2 cross-head screwdriver



- 1. Unscrew the six screws (1).
- 2. Remove the handle half shell (2).

- 3
- 3. Unscrew the screw (3).
- 4. Remove the cable clamp (4).



5. Remove the terminals (5).

C-SC_CSSM

Page 28 of 75




Milling

Jein


Disassembly

8.3 Removing the handle



6. Open the terminals (1) and remove the cables.

- 7. Remove the switch (2).
- 8. Unscrew the two screws (3) and remove the electronics.
- 9. Remove the handle half shell (4).





8.4 Removing the housing


8.4.1 Removing the electronics

Steps that must be completed:

- Remove handle

Tools:

- Torx T15
- PH2 cross-head screwdriver



- 1. Simultaneously press the lugs (1).
- 2. Remove the electronics (2).




8.4.2 Removing the carbon brushes

Steps that must be completed:

- Remove handle

Tools:

- Torx T15
- Long-nosed pliers
- Assembly aid



- 3. Unscrew the screw (1).
- 4. Remove the cover (2).

- 5. Lift up the spring (**3**).
- 6. Remove the carbon brush (4).
- 7. Remove the cable (5).
- 8. Remove the carbon brush holder (6).
- 9. Repeat steps 1 to 6 on the opposite side of the machine.

6

4

3

5



34130533060

Printed in Germany

34130533060 Printed in Germany



8.4.3 Removing the gearbox housing

Steps that must be completed:

- Removing the milling head
- Removing the handle (milling head)

Tools:

- Torx T15
- Plastic hammer



1. Remove the four screws (1).

2. Remove the gearbox housing.

Photo shows similar product	





8.4.3 Removing the gearbox housing

Steps that must be completed:

- Removing the milling head
- Removing the handle
- Removing the switch
- Removing the carbon brushes
- Removing the gearbox housing

Tools:

- Slotted screwdriver



1. Remove the air guide ring (1).

2. Remove the pushbutton (2).



C-SC_CSSM

Version 1.0




Milling



Disassembly

8.4.3 Removing the gearbox housing



- 3. Remove the spiral spring (1).
- 4. Remove the sealing ring (2).
- 5. Remove the bolt (3).



8.5 Removing the motor

8.5.1 Removing the stator

Steps that must be completed:

- Removing the milling head
- Removing the handle
- Removing the switch
- Removing the carbon brushes
- Removing the gearbox housing

Tools:

- Torx T20
- Torx T15
- Plastic hammer



Remove the air guide ring (1).

2. Remove the stator.

1.



Version 1.0



34130533060

Printed in Germany



8.5.1 Removing the stator





Disassembly


8.5.2 Removing the armature

Steps that must be completed:

- Removing the milling head
- Removing the handle
- Removing the switch
- Removing the carbon brushes
- Removing the gearbox housing

Tools:

- Plastic hammer



1. Remove the armature (1).





Disassembly



8.5.3 Disassembling the armature

Steps that must be completed:


- Removing the milling head
- Removing the handle
- Removing the switch
- Removing the carbon brushes
- Removing the gearbox housing
- Removing the armature

Tools:

- Punch, 6 mm diameter
- Arbor press
- Drawing-off plate 64102069007
- Pipe 64101002004
- Drawing-off socket cap 64104150008
- Chuck cone 26 mm 64107026000 19 mm 64107019007



1. Remove the bearing bush (1).



2. Remove the bevel pinion (2).


16.04.2020



Fein

Disassembly

8.5.3 Disassembling the armature




3. Remove the magnet (1).

(i) INFORMATION

The magnet is destroyed during removal and must be replaced.

- 4. Position the spacer sleeve (2).
- 5. Remove the grooved ball bearing (3).
- 6. Remove the plate (4).
- 7. Remove the grooved ball bearing (5).







8.5.4 Removing the gearbox housing

Steps that must be completed:

- Removing the milling head
- Removing the handle
- Removing the switch
- Removing the carbon brushes
- Removing the gearbox housing

Tools:

- Slotted screwdriver



1. Remove the air guide ring (1).

2. Remove the pushbutton (2).






yeim

Disassembly

8.5.4 Removing the gearbox housing



- 3. Remove the spiral spring (1).
- 4. Remove the sealing ring (2).
- 5. Remove the bolt (3).






9 Assembly

9.1 Assembling the motor

9.1.1 Assembling the armature

Tools:

- Arbor press
- Ball bearing support 19 mm; 26 mm



1. Position the plate (1).

- 2. Press on the grooved ball bearing (2).
- 3. Position the spacer sleeve (3).
- 4. Press on the bevel pinion (4).
- 5. Press on the grooved ball bearing (5).

(i) INFORMATION

Use a new magnet for assembly each time.

! Νοτε!

Damage to the magnet.

The magnet can be damaged by excessive force.

Carefully press on the magnet.

- 6. Press on the magnet (6).
- 7. Position the bearing bush (7).





9.1.2 Positioning the armature

Steps that must be completed:

- Assembling the gearbox housing
- Assembling the armature



(i) INFORMATION

The plate must lie in the recess of the air guide ring.

1. Press in the armature (1).



Damage to the gearbox and/or the motor.

The axial displacement of the armature leads to damage to the gearbox and/or the motor.


If the armature can be pulled out of the gearbox head by hand, the gearbox housing must be replaced.



9.1.3 Fitting the stator

Tools:

- Arbor press
- Pressure piece 64122003000
- Sleeve, 40 mm outer diameter, 26 mm inner diameter




Position the stator (1).

1.



Ensure that the stator (1) is in the correct position.

34130533060 Printed in Germany



i Information

Ensure that the cables are in the correct position.



Page 44 of 75



yein

Assembly

9.1.3 Fitting the stator

2. Position the sleeve (1).

i) INFORMATION

Ensure that the sleeve lies between the studs (2).



2

1



3. Insert the pressure piece (**3**).

C-SC_CSSM

Version 1.0

16.04.2020

Page 45 of 75



Assembly

34130533060 Printed in Germany



9.1.3 Fitting the stator



4. Press in the stator (1).

5. Position the air guide ring (2).

Page 46 of 75




Assembly


34130533060 Printed in Germany



9.2 Fitting the housing

9.2.1 Assembling the gearbox housing





5

1. Position the spiral spring (1) and the bolt (2) with sealing ring (3).

2. Position the pushbutton (4).

3. Position the air guide ring (5).



34130533060 Printed in Germany




9.2.2 Positioning the gearbox housing

Steps that must be completed:

- Assembling the gearbox housing

Tools:

- Torx T20



4. Position the gearbox housing (1).

- 5. Screw in the four screws (2) [2.7 Nm].






9.2.3 Positioning the carbon brushes

Steps that must be completed:


- Assembling the gearbox housing
- Assembling the armature
- Positioning the armature
- Fitting the stator
- Positioning the gearbox housing

Tools:

- Assembly aid
- Torx T15



- 1. Position the carbon brush holder (1).
- 2. Connect the cable (2).
- 3. Repeat steps 1 and 2 on the opposite side of the machine.



4. Position the cables (3).




4

Assembly

yein

9.2.3 Positioning the carbon brushes



- 5. Connect the cable (1).
- 6. Position the carbon brush (2).
- 7. Position the spring (3).

Applies to KFH 17-15 RT 120 V:

Applies to KFH 17-15 RT 120 V:

Connect the choke (5).

8. Position the cables (4).



C-SC_CSSM

Version 1.0

16.04.2020

Page 50 of 75


9.



Assembly



9.2.3 Positioning the carbon brushes



- 10. Position the cover (1).
- 11. Screw in the screw (2) [1.5 Nm].
- 12. Repeat steps 6 to 10 on the opposite side of the machine.




9.2.4 Fitting the switch

Steps that must be completed:

- Assembling the gearbox housing
- Assembling the armature
- Positioning the armature
- Fitting the stator
- Positioning the gearbox housing


Tools:

- PH2 cross-head screwdriver



- 1. Position the cable (1).
- 2. Position the cable (2).
- 3. Screw in the screw (3) $[0.8 \text{ Nm} \pm 0.2 \text{ Nm}]$.

- 4. Position the cable (4).
- 5. Position the cable (5).
- 6. Screw in the screw (6) $[0.8 \text{ Nm} \pm 0.2 \text{ Nm}]$.










9.2.5 Positioning the electronics

Steps that must be completed:


- Assembling the gearbox housing
- Assembling the armature
- Positioning the armature
- Fitting the stator
- Positioning the gearbox housing



2

1. Position the cable (1).

2. Position the cable (2).



3. Position the electronics (**3**).



Ensure that the cables (4) are in the correct position.


Version 1.0





Assembly


9.2.5 Positioning the electronics



4. Open the two terminals (1) and connect the cables.

(i) INFORMATION

Route the cables so that they do not cover the opening (2).





Jein

9.3 Assembling the handle

9.3.1 Assembling the handle (applies to KFH17-15R)


Tools:		
- Torx T15		
- Assembly aid		
	1.	Connect the cables (1).
	2.	Position the terminal (2).
	3.	Position the cables (3).
$\begin{pmatrix} 4 \\ 5 \\ \hline \end{pmatrix}^6$	4.	Position the cable with the plug (4).
	5.	Position the cable clamp (5).
	6.	Screw in the screw (6) [1.5 Nm].



Assembly



9.3.1 Assembling the handle (applies to KFH17-15R)



- 7. Position the handle half shell (2).
- 8. Screw in the six screws (3) [1.5 Nm].

i) INFORMATION

Observe the screwdriving sequence.




Assembly

Jein

9.3.2 Assembling the handle (applies to KFH17-15RT 120V)

Tools:

- Torx T15
- Assembly aid



1. Position the handle half shell (1).

- 2. Position the switch (2).
- 3. Position the cables (3).



Press the cables as deep as possible into the recess.


- 4
- 4. Connect the cables (4).





Assembly



9.3.2 Assembling the handle (applies to KFH17-15RT 120V)







5. Position the terminal (1).

6. Position the cables (2).


- 7. Position the cable with the plug (3).
- 8. Position the cable clamping piece (4).
- 9. Screw in the screw (5) [1.5 Nm].



Assembly




9.3.2 Assembling the handle (applies to KFH17-15RT 120V)



i)	INFORMATION	

Note the position of the choke.

10. Position the choke (1).



- 11. Position the handle half shell (2).
- 12. Screw in the six screws (3) [1.5 Nm].



Observe the screwdriving sequence.



9.4 Assembling the milling head

9.4.1 Assembling the grooved ball bearing

Tools:

- Arbor press
- Sleeve, 55 mm outer diameter, 40 mm inner diameter



1. Press in the grooved ball bearings (1).

2. Position the circlip (2).










9.4.2 Assembling the drive shaft

Steps that must be completed:

- Assembling the grooved ball bearing

Tools:

- Arbor press
- Sleeve, 40 mm outer diameter, 30 mm inner diameter







(i) INFORMATION

Apply grease to the sealing ring.

1. Position the sealing ring (1).

i) INFORMATION

Apply grease to the sealing ring.

2. Position the sealing ring (2).

- 3. Position the sealing ring (3).
- 4. Position the drive shaft (4).



Assembly

34130533060 Printed in Germany



9.4.2 Assembling the drive shaft



5. Press in the drive shaft (1).





Apply Loctite 242 to the thread.



34130533060 Printed in Germany



9.4.3 Assembling the flywheel

Steps that must be completed:

- Assembling the grooved ball bearing
- Assembling the drive shaft

Tools:

- Plastic hammer
- Hook and pin wrench 95/100
- Mounting device 64122134000







1. Secure the bearing housing (1) with the mounting device.

2. Position the flywheel (2).

3. Screw in the flywheel.

C-SC_CSSM	
-----------	--

Version 1.0



yein

Assembly

9.4.3 Assembling the flywheel



4. Position the springs (1).

(i) INFORMATION

Apply grease to the springs and the spring magazine. Note the position of the springs.

5. Position the bearing housing (2).






Assembly

9.4.4 Assembling the grooved ball bearing

Tools:

- Arbor press
- Sleeve, 41 mm outer diameter
- Circlip pliers





2. Press in the grooved ball bearing.

3. Position the circlip (2).







34130533060 Printed in Germany -

-

Tools:

Assembly

Steps that must be completed:

Assembling the grooved ball bearing

34130533060 Printed in Germany

9.4.5 Assembling the drive shaft (with needle bearing)

Press in the needle bearing (2). 3.

Position the washer (1).

Position the needle bearing (2).









Assembly

Fein

9.4.5 Assembling the drive shaft (with needle bearing)



4. Position the drive shaft (1).



5. Press in the drive shaft.

- 6. Position the washer (2).
- 7. Position the sealing ring (3).





9.4.6 Assembling the crown wheel

Steps that must be completed:

- Assembling the grooved ball bearing
- Assembling the drive shaft (with needle bearing)

Tools:


- Arbor press
- Dial gauge
- Sleeve, 30 mm outer diameter, 18.5 mm inner diameter
- Sleeve, 17 mm outer diameter, 11 mm inner diameter
- Sleeve, 30 mm outer diameter
- Circlip pliers



2. Press in the crown wheel.

Position the crown wheel (1).

1.



(i) INFORMATION

The bulge of the washer must point in the direction of the circlip.

- 3. Position the washer (1).
- 4. Position the circlip (2).

C-SC_CSSM

Version 1.0

16.04.2020

Page 68 of 75

All rights reserved by FEIN, especially in case of property rights applications. FEIN retains all rights of disposal, such as copying and circulation.

Jein

Assembly

9.4.6 Assembling the crown wheel







Press the circlip into the groove of the drive shaft.

5. Press in the circlip (2).

(i) INFORMATION

Use new shims for assembly each time.

6. Position the shims (**3**).

7. Measure the planar play every 90°.



i) INFORMATION

Maximum planar play 0.09 mm

Version 1.0



34130533060 Printed in Germany



9.4.7 Assembling the gearbox unit

Steps that must be completed:

- Assembling the grooved ball bearing
- Assembling the drive shaft
- Assembling the drive shaft (with needle bearing)
- Assembling the crown wheel

Tools:

- Torx T20
- Socket head wrench, 4 mm



1. Fill the gearbox grease.



Position the housing (2) correctly.

) INFORMATION

2.

İ

Apply Loctite 242 thread locking compound to the threads.

3. Screw in the four screws (3) [4 Nm].



- 1. Perform a test run.
- 2. Check gear backlash by turning the drive shaft (4).
- 3. If there is no gear backlash, a further shim must be inserted between the milling head and the gearbox housing.

C-SC_CSSM

Version 1.0

16.04.2020

Page 70 of 75




Assembly



9.4.7 Assembling the gearbox unit



 Position the bearing housing (1) Other image



(i) INFORMATION

Apply Loctite 242 thread locking compound to the screws.

5. Screw in the four screws (2) [3.6 Nm].



Assembly

yein

9.4.8 Assembling the handle (milling head)

Tools:

- Socket head wrench, 3 mm
- Socket head wrench, 5 mm



1. Position the handle (1).

(i) INFORMATION

Apply Loctite 242 thread locking compound to the screws.

- 2. Screw in the screw (2) [10 Nm].
- 3. Repeat step 2 on the opposite side of the machine.



4. Position the holder (3).

i) INFORMATION

Apply Loctite 242 thread locking compound to the screws.

5. Screw in the four screws (4) [3 Nm].






9.4.9 Assembling the guide plate unit

Tools:

- Torx T25
- Torx T20
- Open-end wrench size 15
- Socket head wrench, 5 mm
- Slotted screwdriver







(i) INFORMATION

Apply Loctite 242 thread locking compound to the thread of the locking knob (1).

1. Turn in the locking knob (1).

i) INFORMATION

Apply grease to the thread of the screw.

2. Screw in the screw (2).

i) INFORMATION

Apply grease to the thread of the holder (3).

Position the holder (3).

3.

i) INFORMATION

Apply Loctite 242 thread locking compound to the threads in the adjusting ring.

- 4. Position the holder (4).
- 5. Screw in the four screws (5) [4 Nm].

Version 1.0

16.04.2020

Page 73 of 75








9.4.9 Assembling the guide plate unit



Position the sleeve (3).
Sleeve first on gearbox unit: Diagram



(i) INFORMATION

Apply Loctite 242 thread locking compound to the screws.

- 1. Position the guide plate (1).
- 2. Screw in the four screws (2) [4 Nm].





Position the guide plate unit.
Photo similar

(i) Information

Apply Loctite 242 thread locking compound to the screws.

4. Screw in the three screws (4) [6 N].

Version 1.0





Inspection following repairs

10 Inspection following repairs

	Always:	Visual inspection
		Speed check
		Insert tool
		Testing (e. g., demo material 1 87 20 198 00 0)
Mains-operated machines:		Electrical safety test
If restart lock present:		Check restart lock
Brake function available:		Brake function check

C-SC_	CSSM
C-SC_	CSSM

